

GAIN TONE LEVEL

## **Operation:**

- Insert a 9V battery (2) or connect a regulated 9V power supply adaptor to the DC jack (4).
- Connecting an instrument to the input jack (3) will automatically switch the unit on.
- Connect your amplifier to the output jack (6). Select your desired sound with the 3 control knobs (7, 8, 9). (see Sound examples)
- Pressing the pedal (1) switches the unit on or off.
- Instead using this unit on the frontstage, you can place it with your equipment and control it with a standard momentary footswitch connected to the remote jack (5).
- Before changing the battery (2) always unplug the input jack (3) to switch the unit off.
- We suggest to use a regulated 9V power supply adaptor to keep our environment clean.
- Power supply specifications: see imprint on bottom of unit. Thank you.

## Important notes:

- Avoid using this unit in extreme humidity, heat or dust environment.
- When the unit is not in use for longer periods, remove the battery (2) to prevent damages by battery leakage.
- Also unplug the input (3) to prevent wasting battery life when the unit is not in use.

## **Function:**

- (3) IN jack: Inserting a plug switches the unit on.
- (4) 9V DC jack: Connect a regulated 9V power supply unit.
- (5) REMOTE jack: The ON / OFF-function can be remote controlled by a momentary switch, connected to the REMOTE jack (5). Intelligent switching devices (like the Nobels MS-4 or MF-2) also can remote control the unit.
- (6) OUT jack: This output delivers a low impedance signal best for the input of your amplifier.
- (7) GAIN Regler: This control adjusts the amount of the FUZZ effect. Turning the pot to the right increases the drive and adds more and more overtones to the signal.
- (8) **TONE Regler:** This control adjusts the amount of high frequencies. Right position = max. overtones. Left position = very deep sound.
- (9) LEVEL control: Adjusts the volume. Attention: It might be VERY loud!
- (10) LED: This Led shows the state of the effect. LED on = Effect on.